



Republic of the Philippines
CIVIL AVIATION AUTHORITY OF THE PHILIPPINES

MEMORANDUM CIRCULAR NO. 023-2025

TO : ALL AERODROME OPERATORS

SUBJECT : AMENDMENT TO AD 1 OF THE AERONAUTICAL INFORMATION PUBLICATION (AIP)

DATE : 11 April 2025

Under Section AD 1, subsection AD 1.1, subsubsection 2, paragraph 2.1 of the Aeronautical Information Publication (AIP), it expressly provides the following:

2.1 'The administration of all national aerodromes except for Ninoy Aquino International Airport (NAIA), Mactan-Cebu International Airport (MCIA), Subic Bay International Airport (SBMA), Diosdado Macapagal International Airport, Diosdado Macapagal International Airport (DMIA), Godofredo P. Ramos Principal Airport and San Fernando Community Airport which are administered by Manila International Airport Authority (MIAA), Mactan-Cebu International Airport Authority (MCIAA), Subic Bay Metropolitan Authority (SBMA), Clark International Airport (CIAC), TransAire Development Holdings Corporation and Poro Point Management Corporation, respectively, is the responsibility of the Aerodrome Development Management Service (ADMS), Civil Aviation Authority of the Philippines.

Moreover, the Civil Aviation Regulations (CAR) governing Aerodromes and Manual of Standards (MOS) for Aerodromes requires aerodrome operators to ensure that any changes involving its operations has been properly processed pursuant to the notification and reporting requirements promulgated by the Aeronautical Information Service (AIS) of the Civil Aviation Authority of the Philippines.

This notification and reporting requirements includes the issuance of Notice to Airmen (NOTAM) as well as the publication of accurate and updated aeronautical data and aeronautical information and aeronautical charts.

However, several changes under the AIP is needed such as the aforementioned AD 2.1 as well as other relevant issuances thereto to ensure it conforms with the fast changing development in the aviation industry.

Reason for which, Section AD 1, subsection AD 1.1, subsubsection 2, paragraph 2.1 under the AIP is hereby amended and read as follows:

2.1 The administration of all aerodromes shall be the responsibility of Airport Managers appointed and/or designated by the Civil

CIVIL AVIATION AUTHORITY
OF THE PHILIPPINES
CERTIFIED PHOTOCOPY
(NOT VALID WITH ERASURES/ALTERATION)

[Signature] 4-24-2025
MADONNA L. OROCIO
Records Officer II
Central Records & Archives Division



Republic of the Philippines
CIVIL AVIATION AUTHORITY OF THE PHILIPPINES

Aviation Authority of the Philippines (CAAP) except for airports operated / owned by other government authorities (as mandated by law) or private entities.

The Authority's Aerodrome Development and Management Service (ADMS) which has been the primary or lead office in facilitating the process of filing and accomplishing Aeronautical Information Promulgation Advice Form (AIPAF) involving activities whether it is planned or unplanned within all CAAP owned airports shall be tasked to conduct change management process to ensure smooth transition and turn-over of responsibilities involving these changes.

Airports operated / owned by other government authorities (as mandated by law) or private entities are hereby encouraged to coordinate with the AIS to ensure that all of these changes are appropriately undertaken.

If necessary, the CAAP's Air Traffic Service (ATS) and Air Navigation Service (ANS) shall be coordinated in all activities (planned or unplanned) in your respective airports requiring the accomplishment of AIPAF.

Further, all are required to observe or comply with the below mentioned documents in the preparation and submission of AIPAF:


1. Revised Guidelines in Accomplishing AIPAF¹;
2. Revised Annex B.1² NOTAM / AIP Supplement (Planned Activity); and
3. Revised Annex B.2³ AIRAC AIP Amendment / AIRAC AIP Supplement (Planned Activity)

All revised provisions and documents under the AIP as mentioned above shall be duly published in the AIP for widest dissemination and information.

All Memoranda and/or Orders issued in conflict herewith shall be rescinded.

This Memorandum Circular shall take effect immediately upon its issuance and remain as such, until and unless revoked or modified.

Be guided accordingly.


LTGEN RAUL L. DEL ROSARIO AFP (RET)
Director General

¹ Annex "A"

² Annex "B"

³ Annex "C"

CIVIL AVIATION AUTHORITY
OF THE PHILIPPINES
CERTIFIED PHOTOCOPY
(NOT VALID WITH ERASURES/ALTERATION)

 4-25-2025
MADONIA L. OROCIO
Records Officer II
Central Records & Archives Division

This AIC replaces AIC 004/22 dated 22 April 2022

GUIDELINES IN ACCOMPLISHING THE AERONAUTICAL INFORMATION PROMULGATION ADVICE FORM (AIPAF)

I. INTRODUCTION

The Aeronautical Information Service (AIS) Quality Management System (QMS) establishes the guidelines in accomplishing the AIPAF to assist the data originator, standardize the presentation of the raw data and facilitate the processing thereof at the AIS Department.

The electronic template of AIPAF can be downloaded from <https://caap.gov.ph/forms/> or ais.caap.gov.ph or can be requested from AIS Help Desk through the email address: ais_operations@caap.gov.ph.

The accomplished AIPAF shall be submitted to AIS Department in person, through email to ais_operations@caap.gov.ph or facsimile (+632 8672-7757).

II. DEFINITION OF TERMS

1. **Aeronautical Information Promulgation Advice Form (AIPAF)** – a standard form for data originators to request publication of aeronautical data and/or aeronautical information either as AIP Amendment, AIP Supplement, AIC or NOTAM.
2. **Aeronautical Information Publication (AIP)** – a publication issued by or with the authority of a State containing aeronautical information of a lasting character essential to air navigation.
3. **Aeronautical Information Regulation and Control (AIRAC)** – an acronym signifying a system aimed at advance notification, based on common effective dates, of circumstances that necessitate significant changes in operating practices.
4. **AIP Amendment** – permanent changes to the information contained in the AIP.
5. **AIP Supplement** – temporary changes to the information contained in the AIP which are provided by means of special pages.
6. **AIS Department** – a department of Aeronautical Information Service Group (AISG) designated to receive, assess, collate and publish aeronautical information.
7. **Air Navigation Services Provider (ANSP)** - means air traffic services; communication, navigation and surveillance services; aeronautical information services; search and rescue services; meteorological services.

8. **Approving Authority** – a person with the authority to formally approve the origination and content of the AIPAF.
9. **Data Originator** – an entity that is accountable for data or information origination and/or from which the AIS organization receives aeronautical data and aeronautical information.
11. **NOTAM** – a notice distributed by means of telecommunication containing information concerning the establishment, condition or change in any aeronautical facility, service, procedure or hazard, the timely knowledge of which is essential to personnel concerned with flight operations.
12. **Raw Data** – data collected from data originators subject to AIS verification and validation procedures.
13. **SNOWTAM** – a special series NOTAM given in a standard format providing a surface condition report notifying the presence or cessation of hazardous conditions due to snow, ice, slush, frost, standing water, or water associated with snow ice, slush or frost on the movement area.

III. GUIDELINES

The AIPAF shall be accomplished by the Data Originator requesting for the aeronautical information promulgation.

All AIPAF received by AIS Department shall be subject for verification and review. Erroneous and/or inconsistent raw data shall be returned to the Data Originator for review and correction.

The AIPAF consists of numbered boxes which correspond to the following: (see Annex A - Sample AIPAF):

1. Originator Contact Information

The date when request is accomplished, name of the authorized personnel accomplishing the AIPAF, his/her Section and Office and contact number must be provided to facilitate coordination.

2. AIP Reference

Whenever applicable, the AIP references or the AIP entries that should be changed or affected by the requested promulgation.

3. Type of Promulgation and Reference NOTAM/AIP Supplement/AIC

When the request is for the replacement or cancellation of a NOTAM, AIP Supplement or AIC, the reference number of the NOTAM, AIP Supplement or AIC to be replaced or canceled (e.g. B0001/24 or 001/24) should be provided.

4. Start/End of Activity

Indicate the date and time in which the information shall come into force in the following format:

- a) Start of activity in YYMMDDHHmm format (date-time group in UTC);

Example:

9:00AM, April 08, 2024 shall be presented as 2404080100

Note: 1. For AIP AMDT/SUP, effective date is subject for approval of the AIS Department.

2. For SNOWTAM, specify the date/time of observation/measurement in the following format: **MMDDHHmm**.

- b) End of validity in YYMMDDHHmm format (date-time group in UTC) or PERM

Note: 1. If the validity of information is uncertain, then the approximate duration should be indicated by a date-time group followed by the abbreviation "EST". Any NOTAM using EST must be canceled or replaced before the date-time specified.

2. For SNOWTAM, no need to specify the end of validity. The maximum validity is 8 hours. When no SNOWTAM is issued after 8 hours of a previous SNOWTAM for an aerodrome, the old SNOWTAM will automatically expire.

5. Day/Time Schedule

For activities with specified schedule-periods and times during which the NOTAM is in force, indicate in Day/Time Schedule allocated field in the following format:

- a) (Date)(start-time)-(end-time), (date)(start-time)-(end-time), etc.

Ex. 14 0000-0300, 15 0300-0500 or

MON 0000-0300, TUE 0300-0500

- b) Repetitive event active every day: (start-time)-(end-time)

Ex. 0000-0500

6. Text of NOTAM/AIP Amendment/Supplement/AIC

The text of the NOTAM or SNOWTAM (Runway Condition Report) or information to be published in AIP Amendment, AIP Supplement or AIC must be printed clearly and concisely.

Note: For Minimum Data Requirements and Publication Resolutions, refer to AIC 005/22 – Procedures for the Promulgation of Aeronautical Information by AIRAC, Annex B.

7. Lower/Upper Limit

If the subject is Navigational Warnings: "Airspace Restrictions" or "Warnings", then Lower and Upper Limits are mandatory. Acceptable entries and formats are as follows:

LOWER LIMIT	UPPER LIMIT
SFC	UNL
GND	
XXXXXXFT AGL	XXXXXXFT AGL
XXXXXXFT AMSL	XXXXXXFT AMSL
XXXXXXM AGL	XXXXXXM AGL
XXXXXXM AMSL	XXXXXXM AMSL
FLXXX	FLXXX

NOTE: When the values in Lower Limit and Upper Limit are expressed as "AGL", the provision of lowest and highest terrain elevation of the affected area are mandatory.

8. Data Originator

A. Planned Activities

CAAP and/or Airport Authorities shall designate personnel who will be directly in charge of origination and management of their respective aerodrome data and charts, radio navigational aids/systems data, airspace data, ATS route and other route data, instrument flight procedures, obstacle data, etc., as appropriate.

NOTE: Refer to respective Data Provision Agreement with AIS, if available.

B. Unplanned Activities, Emergency or Unforeseen Events

The data originator of the AIPAF shall be the concerned:

- a) designated reporting officer of the airport; or
- b) facility shift supervisor on duty or highest-ranking officer on duty of relevant ANS providers.

9. Concurrence

9a. Concurrence

If the request has an effect with any established procedure that consequently affects the safe conduct of flight, or if the promulgation requires the concurrence of another entity with regards to "policy" and/or "accuracy of information", coordination with the affected facility or appropriate authority is required. The duly authorized personnel must affix his/her signature on the AIPAF.

9b. Recommend Approval

If the request affects an aerodrome, the Airport Manager or Aerodrome Operator of the affected aerodrome shall affix his/her signature over printed name to recommend the approval of the AIPAF.

10. Approving Authority

A. Planned Activities

The AIPAF shall be signed by the Approving Authority as indicated in Annex B - AIPAF Approval Reference Guide.

- NOTE:**
1. Requests that fall under "Information to be notified by AIRAC" but to be issued as PERM NOTAM shall follow the signatories on Table B.2
 2. Data Originators shall take all necessary measures to submit the fully accomplished AIPAF to AIS not less than 48 hours in advance of the event to which it relates to.

B. Unplanned Activities or Unforeseen Events/Circumstances

The AIPAF shall be approved and signed by the concerned:

- a) authorized personnel responsible for the management and/or operations of the airport (Area/Airport Manager, OIC or its equivalent position); or
- b) authorized personnel responsible for ANSP facility (Officer-In-Charge/Facility-In-Charge/highest-ranking officer on duty).

NOTE: Data originators shall take all reasonable measures to ensure proper coordination with their respective service heads or appropriate authority before submitting the fully accomplished AIPAF to AIS.


ANNEX B - AIPAF APPROVAL REFERENCE GUIDE

The subjects and conditions for planned activities are defined but not limited to the following for the respective AIPAF Approving Authority:

ANNEX B.1 NOTAM/AIRAC AIP SUPPLEMENT (PLANNED ACTIVITY)

ANNEX B.2 AIRAC AIP AMENDMENT/AIRAC AIP SUPPLEMENT (PLANNED ACTIVITY)

ANNEX A - SAMPLE AIPAF

		Republic of the Philippines CIVIL AVIATION AUTHORITY OF THE PHILIPPINES	
Aeronautical Information Promulgation Advice Form (AIPAF)			
To: Aeronautical Information Service Department		1 Originator: _____ Date: _____ Section: _____ Contact No.: _____	
2 AIP Reference (as applicable)		3 AI for Promulgation: <input type="checkbox"/> NEW <input type="checkbox"/> REPLACEMENT <input type="checkbox"/> CANCELLATION Reference NOTAM/AIP SUP/AIC (as applicable): _____	
AIP Section	Page (date)*	Paragraph	Line
Column	4 Start of Activity (as applicable) (YYMMDDHHmm) UTC		End of Validity (as applicable) (YYMMDDHHmm) UTC
5 Day/Time Schedule (as applicable):	_____		
6 Text of NOTAM, AIP Amendment, Supplement and/or AIC (use extra sheets if necessary)			
7 Lower Limit (as applicable): Value: _____ Unit: _____		Upper Limit (as applicable): Value: _____ Unit: _____	
*All AIP Pages affected by each amendment should be quoted. Notes: (for AIS Use only) _____ _____ _____ _____ _____		8 Data Originator: _____ Name/Signature Designation Date	
9a Concurrence: The following Branches/Directorates: <input type="checkbox"/> ATS _____ <input type="checkbox"/> ATS Facility _____ <input type="checkbox"/> ADMS _____ <input type="checkbox"/> FSIS _____ <input type="checkbox"/> CNS _____ <input type="checkbox"/> CNS Facility _____ <input type="checkbox"/> AANSOO _____ <input type="checkbox"/> Others: _____ have been consulted in respect of: Policy <input type="checkbox"/> Accuracy of Information <input type="checkbox"/>		9b Recommend Approval _____ Name/Signature Designation Date	
10 Approving Authority: _____ Name/Signature Designation Date			



Republic of the Philippines
CIVIL AVIATION AUTHORITY OF THE PHILIPPINES

Aeronautical Information Promulgation Advice Form (AIPAF)

INSTRUCTIONS

- This form can be accomplished through handwritten or computerized;
- May add additional page/s as needed; and
- To be filled out by the designated AIS Specialist and/or Data Originator.

ITEM	DESCRIPTION
Originator	Fill-up the Originator Tab (Name of the Person accomplishing the AIPAF) including Section or Organization, Date and Contact Number
AIP Reference	Indicate the AIP References (as applicable) AIP Section, Page (date), Paragraph, Line and Column
AI for Promulgation	Fill-up the Aeronautical Information (AI) for Promulgation; Check the box if New, Replacement or Cancellation. Indicate the Reference number (as applicable) NOTAM, AIP Supplement/AIC.
Start and End of Validity	Indicate the Start of Activity and End of Validity (indicate PERM or EST) YYMMDDHHMM format
Day/Time Schedule	Indicate the Day/Time Schedule (as applicable) The start of the first activity in Item D) shall always correspond to the Item B) date and time. The end of the latest activity period notified in Item D) shall always correspond to the end of the validity of the NOTAM given in Item C).
Text of NOTAM, AIP Amendment, Supplement and AIC	Indicate the text of NOTAM, AIP Amendment, Supplement and/or AIC
Lower and Upper Limit	Lower Limit (Value and Unit) Upper Limit (Value and Unit) If the subject is a "Navigational Warning" or "Airspace Reservation", then Lower and Upper Limits are mandatory. Lower and Upper limit must be in AMSL. For AGL, the Data Originator must indicate the lowest and highest terrain elevation within the area.
Data Originator	Name, Designation, Date (<i>Affix the name and signature of the Data Originator</i>)
Concurrence	The service that has been consulted in respect of policy and accuracy of information. Check appropriate branch and affix initial or signature (<i>If the promulgation requires the approval of another entity with regards to "policy" and/or "accuracy of information", concurrence or coordination with the Appropriate Authority is required and must bear his/her signature on the AIPAF.</i>)
Recommend Approval	The Airport Manager / Aerodrome Operator to recommend approval of the AIPAF (<i>Affix the name and signature of the recommending approval</i>)
Approving Authority	Name, Designation, Date (<i>Affix the name and signature of the Approving Authority</i>)
Notes	Coordination log of the AIS Specialist from the Data Originator

ANNEX B.1 NOTAM/AIRAC AIP SUPPLEMENT (PLANNED ACTIVITY)

	SUBJECT	Data Originator		Approving Authority		Remarks
		CAAP	Non-CAAP	CAAP	Non-CAAP	
1	Approach lighting system	Department Manager of ANS Operations Department	Head of the facility directly in charge of the operation and maintenance of the lighting facility	Service Chief of CNS	Airport Authority Head	For establishment and withdrawal/decommissioning: Data Originator: Service Chief of CNS/Head of the facility directly in charge of the operations and maintenance of lighting facility Approving Authority: Deputy Director General for Operations/Airport Authority Head
2	Aerodrome beacon	Department Manager of ANS Operations Department	Head of the facility directly in charge of the operation and maintenance of the lighting facility	Service Chief of CNS	Airport Authority Head	For establishment and withdrawal/decommissioning: Data Originator: Service Chief of CNS/Head of the facility directly in charge of the operations and maintenance of lighting facility Approving Authority: Deputy Director General for Operations/Airport Authority Head
3	Runway centre line lights	Department Manager of ANS Operations Department	Head of the facility directly in charge of the operation and maintenance of the lighting facility	Service Chief of CNS	Airport Authority Head	For establishment and withdrawal/decommissioning: Data Originator: Service Chief of CNS/Head of the facility directly in charge of the operations and maintenance of lighting facility Approving Authority: Deputy Director General for Operations/Airport Authority Head
4	Landing direction indicator lights	Department Manager of ANS Operations Department	Head of the facility directly in charge of the operation and maintenance of the lighting facility	Service Chief of CNS	Airport Authority Head	For establishment and withdrawal/decommissioning: Data Originator: Service Chief of CNS/Head of the facility directly in charge of the operations and maintenance of lighting facility Approving Authority: Deputy Director General for Operations/Airport Authority Head
5	Runway edge lights	Department Manager of ANS Operations Department	Head of the facility directly in charge of the operation and maintenance of the lighting facility	Service Chief of CNS	Airport Authority Head	For establishment and withdrawal/decommissioning: Data Originator: Service Chief of CNS/Head of the facility directly in charge of the operations and maintenance of lighting facility Approving Authority: Deputy Director General for Operations/Airport Authority Head
6	Sequenced flashing lights	Department Manager of ANS Operations Department	Head of the facility directly in charge of the operation and maintenance of the lighting facility	Service Chief of CNS	Airport Authority Head	For establishment and withdrawal/decommissioning: Data Originator: Service Chief of CNS/Head of the facility directly in charge of the operations and maintenance of lighting facility Approving Authority: Deputy Director General for Operations/Airport Authority Head
7	Pilot-controlled lighting	Department Manager of ANS Operations Department	Head of the facility directly in charge of the operation and maintenance of the lighting facility	Service Chief of CNS	Airport Authority Head	For establishment and withdrawal/decommissioning: Data Originator: Service Chief of CNS/Head of the facility directly in charge of the operations and maintenance of lighting facility Approving Authority: Deputy Director General for Operations/Airport Authority Head

8	High intensity runway lights	Department Manager of ANS Operations Department	Head of the facility directly in charge of the operation and maintenance of the lighting facility	Service Chief of CNS	Airport Authority Head	For establishment and withdrawal/decommissioning: Data Originator: Service Chief of CNS/Head of the facility directly in charge of the operations and maintenance of lighting facility Approving Authority: Deputy Director General for Operations/Airport Authority Head
9	Runway end identifier lights	Department Manager of ANS Operations Department	Head of the facility directly in charge of the operation and maintenance of the lighting facility	Service Chief of CNS	Airport Authority Head	For establishment and withdrawal/decommissioning: Data Originator: Service Chief of CNS/Head of the facility directly in charge of the operations and maintenance of lighting facility Approving Authority: Deputy Director General for Operations/Airport Authority Head
10	Runway alignment indicator lights	Department Manager of ANS Operations Department	Head of the facility directly in charge of the operation and maintenance of the lighting facility	Service Chief of CNS	Airport Authority Head	For establishment and withdrawal/decommissioning: Data Originator: Service Chief of CNS/Head of the facility directly in charge of the operations and maintenance of lighting facility Approving Authority: Deputy Director General for Operations/Airport Authority Head
11	Category II components of approach lighting system	Department Manager of ANS Operations Department	Head of the facility directly in charge of the operation and maintenance of the lighting facility	Service Chief of CNS	Airport Authority Head	For establishment and withdrawal/decommissioning: Data Originator: Service Chief of CNS/Head of the facility directly in charge of the operations and maintenance of lighting facility Approving Authority: Deputy Director General for Operations/Airport Authority Head
12	Low intensity runway lights	Department Manager of ANS Operations Department	Head of the facility directly in charge of the operation and maintenance of the lighting facility	Service Chief of CNS	Airport Authority Head	For establishment and withdrawal/decommissioning: Data Originator: Service Chief of CNS/Head of the facility directly in charge of the operations and maintenance of lighting facility Approving Authority: Deputy Director General for Operations/Airport Authority Head
13	Medium intensity runway lights	Department Manager of ANS Operations Department	Head of the facility directly in charge of the operation and maintenance of the lighting facility	Service Chief of CNS	Airport Authority Head	For establishment and withdrawal/decommissioning: Data Originator: Service Chief of CNS/Head of the facility directly in charge of the operations and maintenance of lighting facility Approving Authority: Deputy Director General for Operations/Airport Authority Head
14	Precision approach path indicator	Department Manager of ANS Operations Department	Head of the facility directly in charge of the operation and maintenance of the lighting facility	Service Chief of CNS	Airport Authority Head	For establishment and withdrawal/decommissioning: Data Originator: Service Chief of CNS/Head of the facility directly in charge of the operations and maintenance of lighting facility Approving Authority: Deputy Director General for Operations/Airport Authority Head
15	All landing area lighting facilities	Department Manager of ANS Operations Department	Head of the facility directly in charge of the operation and maintenance of the lighting facility	Service Chief of CNS	Airport Authority Head	For establishment and withdrawal/decommissioning: Data Originator: Service Chief of CNS/Head of the facility directly in charge of the operations and maintenance of lighting facility Approving Authority: Deputy Director General for Operations/Airport Authority Head

16	Stopway lights	Department Manager of ANS Operations Department	Head of the facility directly in charge of the operation and maintenance of the lighting facility	Service Chief of CNS	Airport Authority Head	For establishment and withdrawal/decommissioning: Data Originator: Service Chief of CNS/Head of the facility directly in charge of the operations and maintenance of lighting facility Approving Authority: Deputy Director General for Operations/Airport Authority Head
17	Threshold lights	Department Manager of ANS Operations Department	Head of the facility directly in charge of the operation and maintenance of the lighting facility	Service Chief of CNS	Airport Authority Head	For establishment and withdrawal/decommissioning: Data Originator: Service Chief of CNS/Head of the facility directly in charge of the operations and maintenance of lighting facility Approving Authority: Deputy Director General for Operations/Airport Authority Head
18	Helicopter approach path indicator	Department Manager of ANS Operations Department	Head of the facility directly in charge of the operation and maintenance of the lighting facility	Service Chief of CNS	Airport Authority Head	For establishment and withdrawal/decommissioning: Data Originator: Service Chief of CNS/Head of the facility directly in charge of the operations and maintenance of lighting facility Approving Authority: Deputy Director General for Operations/Airport Authority Head
19	Visual approach slope indicator system	Department Manager of ANS Operations Department	Head of the facility directly in charge of the operation and maintenance of the lighting facility	Service Chief of CNS	Airport Authority Head	For establishment and withdrawal/decommissioning: Data Originator: Service Chief of CNS/Head of the facility directly in charge of the operations and maintenance of lighting facility Approving Authority: Deputy Director General for Operations/Airport Authority Head
20	Heliport lighting	Department Manager of ANS Operations Department	Head of the facility directly in charge of the operation and maintenance of the lighting facility	Service Chief of CNS	Airport Authority Head	For establishment and withdrawal/decommissioning: Data Originator: Service Chief of CNS/Head of the facility directly in charge of the operations and maintenance of lighting facility Approving Authority: Deputy Director General for Operations/Airport Authority Head
21	Taxiway centre line lights	Department Manager of ANS Operations Department	Head of the facility directly in charge of the operation and maintenance of the lighting facility	Service Chief of CNS	Airport Authority Head	For establishment and withdrawal/decommissioning: Data Originator: Service Chief of CNS/Head of the facility directly in charge of the operations and maintenance of lighting facility Approving Authority: Deputy Director General for Operations/Airport Authority Head
22	Taxiway edge lights	Department Manager of ANS Operations Department	Head of the facility directly in charge of the operation and maintenance of the lighting facility	Service Chief of CNS	Airport Authority Head	For establishment and withdrawal/decommissioning: Data Originator: Service Chief of CNS/Head of the facility directly in charge of the operations and maintenance of lighting facility Approving Authority: Deputy Director General for Operations/Airport Authority Head
23	Runway touchdown zone lights	Department Manager of ANS Operations Department	Head of the facility directly in charge of the operation and maintenance of the lighting facility	Service Chief of CNS	Airport Authority Head	For establishment and withdrawal/decommissioning: Data Originator: Service Chief of CNS/Head of the facility directly in charge of the operations and maintenance of lighting facility Approving Authority: Deputy Director General for Operations/Airport Authority Head

24	Movement area	Head of airport facility directly in charge of the operation and maintenance of the movement and landing area / ADMS*	Head of the facility directly in charge of the operation and maintenance of the movement and landing area	Airport Manager or equivalent or Service Chief of ADMS*	Airport Manager or equivalent	<p>For establishment and withdrawal/decommissioning: Data Originator: Airport Manager or equivalent/Head of the facility directly in charge of the operations and maintenance of movement and landing area Approving Authority: Deputy Director General for Operations/Airport Authority Head</p> <p>*ADMS as Data Originator and Approving Authority on ADMS/DOTr projects, and Airport Manager on airport implemented projects.</p>
25	Bearing strength	Head of airport facility directly in charge of the operation and maintenance of the movement and landing area / ADMS*	Head of the facility directly in charge of the operation and maintenance of the movement and landing area	Airport Manager or equivalent or Service Chief of ADMS*	Airport Manager or equivalent	<p>For establishment and withdrawal/decommissioning: Data Originator: Airport Manager or equivalent/Head of the facility directly in charge of the operations and maintenance of movement and landing area Approving Authority: Deputy Director General for Operations/Airport Authority Head</p> <p>*ADMS as Data Originator and Approving Authority on ADMS/DOTr projects, and Airport Manager on airport implemented projects.</p>
26	Clearway	Head of airport facility directly in charge of the operation and maintenance of the movement and landing area / ADMS*	Head of the facility directly in charge of the operation and maintenance of the movement and landing area	Airport Manager or equivalent or Service Chief of ADMS*	Airport Manager or equivalent	<p>For establishment and withdrawal/decommissioning: Data Originator: Airport Manager or equivalent/Head of the facility directly in charge of the operations and maintenance of movement and landing area Approving Authority: Deputy Director General for Operations/Airport Authority Head</p> <p>*ADMS as Data Originator and Approving Authority on ADMS/DOTr projects, and Airport Manager on airport implemented projects.</p>
27	Declared distances	Head of airport facility directly in charge of the operation and maintenance of the movement and landing area / ADMS*	Head of the facility directly in charge of the operation and maintenance of the movement and landing area	Airport Manager or equivalent or Service Chief of ADMS*	Airport Manager or equivalent	<p>For establishment and withdrawal/decommissioning: Data Originator: Airport Manager or equivalent/Head of the facility directly in charge of the operations and maintenance of movement and landing area Approving Authority: Deputy Director General for Operations/Airport Authority Head</p> <p>*ADMS as Data Originator and Approving Authority on ADMS/DOTr projects, and Airport Manager on airport implemented projects.</p>

28	Taxiing guidance system	Head of airport facility directly in charge of the operation and maintenance of the movement and landing area / ADMS*	Head of the facility directly in charge of the operation and maintenance of the movement and landing area	Airport Manager or equivalent or Service Chief of ADMS*	Airport Manager or equivalent	<p>For establishment and withdrawal/decommissioning: Data Originator: Airport Manager or equivalent/Head of the facility directly in charge of the operations and maintenance of movement and landing area Approving Authority: Deputy Director General for Operations/Airport Authority Head</p> <p>*ADMS as Data Originator and Approving Authority on ADMS/DOTr projects, and Airport Manager on airport implemented projects.</p>
29	Runway arresting gear	Head of airport facility directly in charge of the operation and maintenance of the movement and landing area / ADMS*	Head of the facility directly in charge of the operation and maintenance of the movement and landing area	Airport Manager or equivalent or Service Chief of ADMS*	Airport Manager or equivalent	<p>For establishment and withdrawal/decommissioning: Data Originator: Airport Manager or equivalent/Head of the facility directly in charge of the operations and maintenance of movement and landing area Approving Authority: Deputy Director General for Operations/Airport Authority Head</p> <p>*ADMS as Data Originator and Approving Authority on ADMS/DOTr projects, and Airport Manager on airport implemented projects.</p>
30	Parking area	Head of airport facility directly in charge of the operation and maintenance of the movement and landing area / ADMS*	Head of the facility directly in charge of the operation and maintenance of the movement and landing area	Airport Manager or equivalent or Service Chief of ADMS*	Airport Manager or equivalent	<p>For establishment and withdrawal/decommissioning: Data Originator: Airport Manager or equivalent/Head of the facility directly in charge of the operations and maintenance of movement and landing area Approving Authority: Deputy Director General for Operations/Airport Authority Head</p> <p>*ADMS as Data Originator and Approving Authority on ADMS/DOTr projects, and Airport Manager on airport implemented projects.</p>
31	Daylight markings	Head of airport facility directly in charge of the operation and maintenance of the movement and landing area / ADMS*	Head of the facility directly in charge of the operation and maintenance of the movement and landing area	Airport Manager or equivalent or Service Chief of ADMS*	Airport Manager or equivalent	<p>For establishment and withdrawal/decommissioning: Data Originator: Airport Manager or equivalent/Head of the facility directly in charge of the operations and maintenance of movement and landing area Approving Authority: Deputy Director General for Operations/Airport Authority Head</p> <p>*ADMS as Data Originator and Approving Authority on ADMS/DOTr projects, and Airport Manager on airport implemented projects.</p>

32	Apron	Head of airport facility directly in charge of the operation and maintenance of the movement and landing area / ADMS*	Head of the facility directly in charge of the operation and maintenance of the movement and landing area	Airport Manager or equivalent or Service Chief of ADMS*	Airport Manager or equivalent	<p>For establishment and withdrawal/decommissioning: Data Originator: Airport Manager or equivalent/Head of the facility directly in charge of the operations and maintenance of movement and landing area Approving Authority: Deputy Director General for Operations/Airport Authority Head</p> <p>*ADMS as Data Originator and Approving Authority on ADMS/DOTr projects, and Airport Manager on airport implemented projects.</p>
33	Stop bar	Head of airport facility directly in charge of the operation and maintenance of the movement and landing area / ADMS*	Head of the facility directly in charge of the operation and maintenance of the movement and landing area	Airport Manager or equivalent or Service Chief of ADMS*	Airport Manager or equivalent	<p>For establishment and withdrawal/decommissioning: Data Originator: Airport Manager or equivalent/Head of the facility directly in charge of the operations and maintenance of movement and landing area Approving Authority: Deputy Director General for Operations/Airport Authority Head</p> <p>*ADMS as Data Originator and Approving Authority on ADMS/DOTr projects, and Airport Manager on airport implemented projects.</p>
34	Aircraft stands	Head of airport facility directly in charge of the operation and maintenance of the movement and landing area / ADMS*	Head of the facility directly in charge of the operation and maintenance of the movement and landing area	Airport Manager or equivalent or Service Chief of ADMS*	Airport Manager or equivalent	<p>For establishment and withdrawal/decommissioning: Data Originator: Airport Manager or equivalent/Head of the facility directly in charge of the operations and maintenance of movement and landing area Approving Authority: Deputy Director General for Operations/Airport Authority Head</p> <p>*ADMS as Data Originator and Approving Authority on ADMS/DOTr projects, and Airport Manager on airport implemented projects.</p>
35	Runway	Head of airport facility directly in charge of the operation and maintenance of the movement and landing area / ADMS*	Head of the facility directly in charge of the operation and maintenance of the movement and landing area	Airport Manager or equivalent or Service Chief of ADMS*	Airport Manager or equivalent	<p>For establishment and withdrawal/decommissioning: Data Originator: Airport Manager or equivalent/Head of the facility directly in charge of the operations and maintenance of movement and landing area Approving Authority: Deputy Director General for Operations/Airport Authority Head</p> <p>*ADMS as Data Originator and Approving Authority on ADMS/DOTr projects, and Airport Manager on airport implemented projects.</p>

36	Stopway	Head of airport facility directly in charge of the operation and maintenance of the movement and landing area / ADMS*	Head of the facility directly in charge of the operation and maintenance of the movement and landing area	Airport Manager or equivalent or Service Chief of ADMS*	Airport Manager or equivalent	<p>For establishment and withdrawal/decommissioning: Data Originator: Airport Manager or equivalent/Head of the facility directly in charge of the operations and maintenance of movement and landing area Approving Authority: Deputy Director General for Operations/Airport Authority Head</p> <p>*ADMS as Data Originator and Approving Authority on ADMS/DOTr projects, and Airport Manager on airport implemented projects.</p>
37	Threshold	Head of airport facility directly in charge of the operation and maintenance of the movement and landing area / ADMS*	Head of the facility directly in charge of the operation and maintenance of the movement and landing area	Airport Manager or equivalent or Service Chief of ADMS*	Airport Manager or equivalent	<p>For establishment and withdrawal/decommissioning: Data Originator: Airport Manager or equivalent/Head of the facility directly in charge of the operations and maintenance of movement and landing area Approving Authority: Deputy Director General for Operations/Airport Authority Head</p> <p>*ADMS as Data Originator and Approving Authority on ADMS/DOTr projects, and Airport Manager on airport implemented projects.</p>
38	Runway turning bay	Head of airport facility directly in charge of the operation and maintenance of the movement and landing area / ADMS*	Head of the facility directly in charge of the operation and maintenance of the movement and landing area	Airport Manager or equivalent or Service Chief of ADMS*	Airport Manager or equivalent	<p>For establishment and withdrawal/decommissioning: Data Originator: Airport Manager or equivalent/Head of the facility directly in charge of the operations and maintenance of movement and landing area Approving Authority: Deputy Director General for Operations/Airport Authority Head</p> <p>*ADMS as Data Originator and Approving Authority on ADMS/DOTr projects, and Airport Manager on airport implemented projects.</p>
39	Strip/shoulder	Head of airport facility directly in charge of the operation and maintenance of the movement and landing area / ADMS*	Head of the facility directly in charge of the operation and maintenance of the movement and landing area	Airport Manager or equivalent or Service Chief of ADMS*	Airport Manager or equivalent	<p>For establishment and withdrawal/decommissioning: Data Originator: Airport Manager or equivalent/Head of the facility directly in charge of the operations and maintenance of movement and landing area Approving Authority: Deputy Director General for Operations/Airport Authority Head</p> <p>*ADMS as Data Originator and Approving Authority on ADMS/DOTr projects, and Airport Manager on airport implemented projects.</p>

40	Taxiway(s)	Head of airport facility directly in charge of the operation and maintenance of the movement and landing area / ADMS*	Head of the facility directly in charge of the operation and maintenance of the movement and landing area	Airport Manager or equivalent or Service Chief of ADMS*	Airport Manager or equivalent	<p>For establishment and withdrawal/decommissioning: Data Originator: Airport Manager or equivalent/Head of the facility directly in charge of the operations and maintenance of movement and landing area Approving Authority: Deputy Director General for Operations/Airport Authority Head</p> <p>*ADMS as Data Originator and Approving Authority on ADMS/DOTr projects, and Airport Manager on airport implemented projects.</p>
41	Rapid exit taxiway	Head of airport facility directly in charge of the operation and maintenance of the movement and landing area / ADMS*	Head of the facility directly in charge of the operation and maintenance of the movement and landing area	Airport Manager or equivalent or Service Chief of ADMS*	Airport Manager or equivalent	<p>For establishment and withdrawal/decommissioning: Data Originator: Airport Manager or equivalent/Head of the facility directly in charge of the operations and maintenance of movement and landing area Approving Authority: Deputy Director General for Operations/Airport Authority Head</p> <p>*ADMS as Data Originator and Approving Authority on ADMS/DOTr projects, and Airport Manager on airport implemented projects.</p>
42	Aerodrome	Head of airport facility directly in charge of the operation and maintenance of the AGA - Facilities and Services / ADMS*	Head of the facility directly in charge of the operation and maintenance of the AGA - Facilities and Services	Airport Manager or equivalent or Service Chief of ADMS*	Airport Manager or equivalent	<p>-For establishment and withdrawal/decommissioning: Data Originator: Airport Manager or equivalent/Airport Authority Head Approving Authority: Director General</p> <p>-AIP Supplement only for establishment of Aerodrome</p> <p>*ADMS as Data Originator and Approving Authority on ADMS/DOTr projects, and Airport Manager on airport implemented projects.</p>
43	Friction measuring device	Head of airport facility directly in charge of the operation and maintenance of the AGA - Facilities and Services / ADMS*	Head of the facility directly in charge of the operation and maintenance of the AGA - Facilities and Services	Airport Manager or equivalent or Service Chief of ADMS*	Airport Manager or equivalent	<p>For establishment and withdrawal/decommissioning: Data Originator: Airport Manager or equivalent/Head of the facility directly in charge of the operation and maintenance of the AGA - Facilities and Services Approving Authority: Deputy Director General for Operations/Airport Authority Head</p> <p>*ADMS as Data Originator and Approving Authority on ADMS/DOTr projects, and Airport Manager on airport implemented projects.</p>

44	Ceiling measurement equipment	Head of airport facility directly in charge of the operation and maintenance of the AGA - Facilities and Services / ADMS*	Head of the facility directly in charge of the operation and maintenance of the AGA - Facilities and Services	Airport Manager or equivalent or Service Chief of ADMS*	Airport Manager or equivalent	<p>For establishment and withdrawal/decommissioning: Data Originator: Airport Manager or equivalent/Head of the facility directly in charge of the operation and maintenance of the AGA - Facilities and Services Approving Authority: Deputy Director General for Operations/Airport Authority Head</p> <p>*ADMS as Data Originator and Approving Authority on ADMS/DOTr projects, and Airport Manager on airport implemented projects.</p>
45	Docking system	Head of airport facility directly in charge of the operation and maintenance of the AGA - Facilities and Services / ADMS*	Head of the facility directly in charge of the operation and maintenance of the AGA - Facilities and Services	Airport Manager or equivalent or Service Chief of ADMS*	Airport Manager or equivalent	<p>For establishment and withdrawal/decommissioning: Data Originator: Airport Manager or equivalent/Head of the facility directly in charge of the operation and maintenance of the AGA - Facilities and Services Approving Authority: Deputy Director General for Operations/Airport Authority Head</p> <p>*ADMS as Data Originator and Approving Authority on ADMS/DOTr projects, and Airport Manager on airport implemented projects.</p>
46	Oxygen**	Head of airport facility directly in charge of the operation and maintenance of the AGA - Facilities and Services / ADMS*	Head of the facility directly in charge of the operation and maintenance of the AGA - Facilities and Services	Airport Manager or equivalent or Service Chief of ADMS*	Airport Manager or equivalent	<p>For establishment and withdrawal/decommissioning: Data Originator: Airport Manager or equivalent/Head of the facility directly in charge of the operation and maintenance of the AGA - Facilities and Services Approving Authority: Deputy Director General for Operations/Airport Authority Head</p> <p>*ADMS as Data Originator and Approving Authority on ADMS/DOTr projects, and Airport Manager on airport implemented projects.</p> <p>**Oxygen supplies for aviation usage</p>
47	Firefighting and rescue	Head of airport facility directly in charge of the operation and maintenance of the AGA - Facilities and Services / ADMS*	Head of the facility directly in charge of the operation and maintenance of the AGA - Facilities and Services	Airport Manager or equivalent or Service Chief of ADMS*	Airport Manager or equivalent	<p>For establishment and withdrawal/decommissioning: Data Originator: Airport Manager or equivalent/Head of the facility directly in charge of the operation and maintenance of the AGA - Facilities and Services Approving Authority: Deputy Director General for Operations/Airport Authority Head</p> <p>*ADMS as Data Originator and Approving Authority on ADMS/DOTr projects, and Airport Manager on airport implemented projects.</p>

48	Ground movement control	Head of airport facility directly in charge of the operation and maintenance of the AGA - Facilities and Services / ADMS*	Head of the facility directly in charge of the operation and maintenance of the AGA - Facilities and Services	Airport Manager or equivalent or Service Chief of ADMS*	Airport Manager or equivalent	<p>For establishment and withdrawal/decommissioning: Data Originator: Airport Manager or equivalent/Head of the facility directly in charge of the operation and maintenance of the AGA - Facilities and Services Approving Authority: Deputy Director General for Operations/Airport Authority Head</p> <p>*ADMS as Data Originator and Approving Authority on ADMS/DOTr projects, and Airport Manager on airport implemented projects.</p>
49	Helicopter alighting area/platform	Head of airport facility directly in charge of the operation and maintenance of the AGA - Facilities and Services / ADMS*	Head of the facility directly in charge of the operation and maintenance of the AGA - Facilities and Services	Airport Manager or equivalent or Service Chief of ADMS*	Airport Manager or equivalent	<p>For establishment and withdrawal/decommissioning: Data Originator: Airport Manager or equivalent/Head of the facility directly in charge of the operation and maintenance of the AGA - Facilities and Services Approving Authority: Deputy Director General for Operations/Airport Authority Head</p> <p>*ADMS as Data Originator and Approving Authority on ADMS/DOTr projects, and Airport Manager on airport implemented projects.</p>
50	Oils	Head of airport facility directly in charge of the operation and maintenance of the AGA - Facilities and Services / ADMS*	Head of the facility directly in charge of the operation and maintenance of the AGA - Facilities and Services	Airport Manager or equivalent or Service Chief of ADMS*	Airport Manager or equivalent	<p>For establishment and withdrawal/decommissioning: Data Originator: Airport Manager or equivalent/Head of the facility directly in charge of the operation and maintenance of the AGA - Facilities and Services Approving Authority: Deputy Director General for Operations/Airport Authority Head</p> <p>*ADMS as Data Originator and Approving Authority on ADMS/DOTr projects, and Airport Manager on airport implemented projects.</p>
51	Landing direction indicator	Department Manager of ANS Operations Department	Head of the facility directly in charge of the operation and maintenance of the AGA - Facilities and Services	Service Chief of CNS	Airport Authority Head	<p>For establishment and withdrawal/decommissioning: Data Originator: Service Chief of CNS/Head of the facility directly in charge of the operation and maintenance of the AGA - Facilities and Services Approving Authority: Deputy Director General for Operations/Airport Authority Head</p>
52	Meteorological service	Head of the facility directly in charge of the operation and maintenance of the Meteorological Services / Department Manager of ANS Operations Department	Head of the facility directly in charge of the operation and maintenance of the Meteorological Services	Airport Manager or equivalent or Service Chief of CNS	Airport Manager or equivalent	<p>For establishment: Data Originator: Head of the facility directly in charge of the operation and maintenance of the Meteorological Services Approving Authority: Director General</p>

53	Fog dispersal system	Head of airport facility directly in charge of the operation and maintenance of the AGA - Facilities and Services / ADMS*	Head of the facility directly in charge of the operation and maintenance of the AGA - Facilities and Services	Airport Manager or equivalent or Service Chief of ADMS*	Airport Manager or equivalent	<p>For establishment and withdrawal/decommissioning: Data Originator: Airport Manager or equivalent/Head of the facility directly in charge of the operation and maintenance of the AGA - Facilities and Services Approving Authority: Deputy Director General for Operations/Airport Authority Head</p> <p>*ADMS as Data Originator and Approving Authority on ADMS/DOTr projects, and Airport Manager on airport implemented projects.</p>
54	Heliport	Head of airport facility directly in charge of the operation and maintenance of the AGA - Facilities and Services / ADMS*	Head of the facility directly in charge of the operation and maintenance of the AGA - Facilities and Services	Airport Manager or equivalent or Service Chief of ADMS*	Airport Manager or equivalent	<p>For establishment and withdrawal/decommissioning: Data Originator: Airport Manager or equivalent/Head of the facility directly in charge of the operation and maintenance of the AGA - Facilities and Services Approving Authority: Deputy Director General for Operations/Airport Authority Head</p> <p>*ADMS as Data Originator and Approving Authority on ADMS/DOTr projects, and Airport Manager on airport implemented projects.</p>
55	Transmissometer	Department Manager of ANS Operations Department	Head of the facility directly in charge of the operation and maintenance of the AGA - Facilities and Services	Service Chief of CNS	Airport Authority Head	<p>For establishment and withdrawal/decommissioning: Data Originator: Service Chief of CNS/Head of the facility directly in charge of the operation and maintenance of the AGA - Facilities and Services Approving Authority: Deputy Director General for Operations/Airport Authority Head</p>
56	Fuel availability	Head of airport facility directly in charge of the operation and maintenance of the AGA - Facilities and Services / ADMS*	Head of the facility directly in charge of the operation and maintenance of the AGA - Facilities and Services	Airport Manager or equivalent or Service Chief of ADMS*	Airport Manager or equivalent	<p>For establishment and withdrawal/decommissioning: Data Originator: Airport Manager or equivalent/Head of the facility directly in charge of the operation and maintenance of the AGA - Facilities and Services Approving Authority: Deputy Director General for Operations/Airport Authority Head</p> <p>*ADMS as Data Originator and Approving Authority on ADMS/DOTr projects, and Airport Manager on airport implemented projects.</p>
57	Wind direction indicator	Department Manager of ANS Operations Department	Head of the facility directly in charge of the operation and maintenance of the AGA - Facilities and Services	Service Chief of CNS	Airport Authority Head	<p>For establishment and withdrawal/decommissioning: Data Originator: Service Chief of CNS/Head of the facility directly in charge of the operation and maintenance of the AGA - Facilities and Services Approving Authority: Deputy Director General for Operations/Airport Authority Head</p>

58	Customs/immigration	Head of airport facility directly in charge of the operation and maintenance of the Customs/Immigration Services / ADMS*	Head of the facility directly in charge of the operation and maintenance of the Customs/Immigration Services	Airport Manager or equivalent or Service Chief of ADMS*	Airport Manager or equivalent	For establishment and withdrawal/decommissioning: Data Originator: Airport Manager or equivalent/Airport Authority Head Approving Authority: Director General *ADMS as Data Originator and Approving Authority on ADMS/DOTr projects, and Airport Manager on airport implemented projects.
59	Minimum altitude	Division Chief of the responsible ATS Facility/Section		Service Chief of ATS		For establishment: Data Originator: Service Chief of ATS Approving Authority: Deputy Director General for Operations
60	Control zone (CTR)	Division Chief of the responsible ATS Facility/Section		Service Chief of ATS		For establishment and withdrawal/decommissioning: Data Originator: Service Chief of ATS Approving Authority: Deputy Director General for Operations
61	Air defense identification zone (ADIZ)	Division Chief of the responsible ATS Facility/Section		Service Chief of ATS		For establishment and withdrawal/decommissioning: Data Originator: Service Chief of ATS Approving Authority: Deputy Director General for Operations
62	Control area (CTA)	Division Chief of the responsible ATS Facility/Section		Service Chief of ATS		For establishment and withdrawal/decommissioning: Data Originator: Service Chief of ATS Approving Authority: Deputy Director General for Operations
63	Flight information region (FIR)	Division Chief of the responsible ATS Facility/Section		Service Chief of ATS		For establishment and withdrawal/decommissioning: Data Originator: Service Chief of ATS Approving Authority: Director General
64	Upper control area (UTA)	Division Chief of the responsible ATS Facility/Section		Service Chief of ATS		For establishment and withdrawal/decommissioning: Data Originator: Service Chief of ATS Approving Authority: Deputy Director General for Operations
65	Minimum usable flight level	Division Chief of the responsible ATS Facility/Section		Service Chief of ATS		For establishment: Data Originator: Service Chief of ATS Approving Authority: Deputy Director General for Operations
66	Area navigation route	Division Chief of the responsible ATS Facility/Section		Service Chief of ATS		For establishment and withdrawal/decommissioning: Data Originator: Service Chief of ATS Approving Authority: Deputy Director General for Operations
67	Oceanic control area (OCA)	Division Chief of the responsible ATS Facility/Section		Service Chief of ATS		For establishment and withdrawal/decommissioning: Data Originator: Service Chief of ATS Approving Authority: Deputy Director General for Operations
68	ATS route	Division Chief of the responsible ATS Facility/Section		Service Chief of ATS		For establishment and withdrawal/decommissioning: Data Originator: Service Chief of ATS Approving Authority: Deputy Director General for Operations

69	Terminal control area (TMA)	Division Chief of the responsible ATS Facility/Section		Service Chief of ATS		For establishment and withdrawal/decommissioning: Data Originator: Service Chief of ATS Approving Authority: Deputy Director General for Operations
70	Upper flight information region (UIR)	Division Chief of the responsible ATS Facility/Section		Service Chief of ATS		For establishment and withdrawal/decommissioning: Data Originator: Service Chief of ATS Approving Authority: Deputy Director General for Operations
71	Upper advisory area (UDA)	Division Chief of the responsible ATS Facility/Section		Service Chief of ATS		For establishment and withdrawal/decommissioning: Data Originator: Service Chief of ATS Approving Authority: Deputy Director General for Operations
72	Significant point	Division Chief of the responsible ATS Facility/Section		Service Chief of ATS		For establishment and withdrawal/decommissioning: Data Originator: Service Chief of ATS Approving Authority: Deputy Director General for Operations
73	Aerodrome traffic zone (ATZ)	Division Chief of the responsible ATS Facility/Section		Service Chief of ATS		For establishment and withdrawal/decommissioning: Data Originator: Service Chief of ATS Approving Authority: Deputy Director General for Operations
74	Automatic terminal information service (ATIS)	Division Chief of the responsible ATS Facility/Section		Service Chief of ATS		For establishment and withdrawal/decommissioning: Data Originator: Service Chief of ATS Approving Authority: Deputy Director General for Operations
75	ATS reporting office	Division Chief of the responsible ATS Facility/Section		Service Chief of ATS		For establishment and withdrawal/decommissioning: Data Originator: Service Chief of ATS Approving Authority: Deputy Director General for Operations
76	Area control centre (ACC)	Division Chief of the responsible ATS Facility/Section		Service Chief of ATS		For establishment and withdrawal/decommissioning: Data Originator: Service Chief of ATS Approving Authority: Deputy Director General for Operations
77	Flight information service	Division Chief of the responsible ATS Facility/Section		Service Chief of ATS		For establishment and withdrawal/decommissioning: Data Originator: Service Chief of ATS Approving Authority: Deputy Director General for Operations
78	Aerodrome flight information service (AFIS)	Division Chief of the responsible ATS Facility/Section		Service Chief of ATS		For establishment and withdrawal/decommissioning: Data Originator: Service Chief of ATS Approving Authority: Deputy Director General for Operations
79	Flow control centre	Division Chief of the responsible ATS Facility/Section		Service Chief of ATS		For establishment and withdrawal/decommissioning: Data Originator: Service Chief of ATS Approving Authority: Deputy Director General for Operations
80	Oceanic area control centre (OAC)	Division Chief of the responsible ATS Facility/Section		Service Chief of ATS		For establishment and withdrawal/decommissioning: Data Originator: Service Chief of ATS Approving Authority: Deputy Director General for Operations

81	Approach control service (APP)	Division Chief of the responsible ATS Facility/Section		Service Chief of ATS		For establishment and withdrawal/decommissioning: Data Originator: Service Chief of ATS Approving Authority: Deputy Director General for Operations
82	Flight service station (FSS)	Division Chief of the responsible ATS Facility/Section		Service Chief of ATS		For establishment and withdrawal/decommissioning: Data Originator: Service Chief of ATS Approving Authority: Deputy Director General for Operations
83	Aerodrome control tower (TWR)	Division Chief of the responsible ATS Facility/Section		Service Chief of ATS		For establishment and withdrawal/decommissioning: Data Originator: Service Chief of ATS Approving Authority: Deputy Director General for Operations
84	Upper area control centre (UACC)	Division Chief of the responsible ATS Facility/Section		Service Chief of ATS		For establishment and withdrawal/decommissioning: Data Originator: Service Chief of ATS Approving Authority: Deputy Director General for Operations
85	VOLMET broadcast	Division Chief of the responsible ATS Facility/Section		Service Chief of ATS		For establishment and withdrawal/decommissioning: Data Originator: Service Chief of ATS Approving Authority: Deputy Director General for Operations
86	Upper advisory service	Division Chief of the responsible ATS Facility/Section		Service Chief of ATS		For establishment and withdrawal/decommissioning: Data Originator: Service Chief of ATS Approving Authority: Deputy Director General for Operations
87	Standard instrument arrival (STAR)	Division Chief of the responsible ATS Facility/Section		Service Chief of ATS		For establishment and withdrawal/decommissioning: Data Originator: Service Chief of ATS/Airport Authority Head Approving Authority: Deputy Director General for Operations
88	Standard VFR arrival	Division Chief of the responsible ATS Facility/Section		Service Chief of ATS		For establishment and withdrawal/decommissioning: Data Originator: Service Chief of ATS/Airport Authority Head Approving Authority: Deputy Director General for Operations
89	Contingency procedures	Division Chief of the responsible ATS Facility/Section		Service Chief of ATS		For establishment and withdrawal/decommissioning: Data Originator: Service Chief of ATS/Airport Authority Head Approving Authority: Deputy Director General for Operations
90	Standard instrument departure (SID)	Division Chief of the responsible ATS Facility/Section		Service Chief of ATS		For establishment and withdrawal/decommissioning: Data Originator: Service Chief of ATS/Airport Authority Head Approving Authority: Deputy Director General for Operations
91	Standard VFR departure	Division Chief of the responsible ATS Facility/Section		Service Chief of ATS		For establishment and withdrawal/decommissioning: Data Originator: Service Chief of ATS/Airport Authority Head Approving Authority: Deputy Director General for Operations
92	Flow control procedure	Division Chief of the responsible ATS Facility/Section		Service Chief of ATS		For establishment and withdrawal/decommissioning: Data Originator: Service Chief of ATS Approving Authority: Deputy Director General for Operations

93	Holding procedure	Division Chief of the responsible ATS Facility/Section		Service Chief of ATS		For establishment and withdrawal/decommissioning: Data Originator: Service Chief of ATS/Airport Authority Head Approving Authority: Deputy Director General for Operations
94	Instrument approach procedure	Division Chief of the responsible ATS Facility/Section		Service Chief of ATS		For establishment and withdrawal/decommissioning: Data Originator: Service Chief of ATS/Airport Authority Head Approving Authority: Deputy Director General for Operations
95	VFR approach procedure	Division Chief of the responsible ATS Facility/Section		Service Chief of ATS		For establishment and withdrawal/decommissioning: Data Originator: Service Chief of ATS/Airport Authority Head Approving Authority: Deputy Director General for Operations
96	Flight plan processing, filing and related contingency	Division Chief of the responsible ATS Facility/Section		Service Chief of ATS		For establishment and withdrawal/decommissioning: Data Originator: Service Chief of ATS Approving Authority: Deputy Director General for Operations
97	Aerodrome operating minima (ATS procedure)	Division Chief of the responsible ATS Facility/Section		Service Chief of ATS		For establishment and withdrawal/decommissioning: Data Originator: Service Chief of ATS Approving Authority: Deputy Director General for Operations Note: When aerodrome operating minima is established by the Airport Operators.
98	Noise operating restrictions	Division Chief of the responsible ATS Facility/Section	Airport Authority Head	Service Chief of ATS	Deputy Director General for Operations	For establishment: Data Originator: Service Chief of ATS/Airport Authority Head Approving Authority: Deputy Director General for Operations
99	Obstacle clearance altitude and height	Division Chief of the responsible ATS Facility/Section	Airport Authority Head	Service Chief of ATS	Deputy Director General for Operations	For establishment: Data Originator: Service Chief of ATS/Airport Authority Head Approving Authority: Deputy Director General for Operations
100	Radio failure procedure	Division Chief of the responsible ATS Facility/Section	Airport Authority Head	Service Chief of ATS	Deputy Director General for Operations	For establishment: Data Originator: Service Chief of ATS Approving Authority: Deputy Director General for Operations
101	Transition altitude or transition level	Division Chief of the responsible ATS Facility/Section	Airport Authority Head	Service Chief of ATS	Deputy Director General for Operations	For establishment: Data Originator: Service Chief of ATS/Airport Authority Head Approving Authority: Deputy Director General for Operations
102	Missed approach procedure	Division Chief of the responsible ATS Facility/Section	Airport Authority Head	Service Chief of ATS	Deputy Director General for Operations	For establishment: Data Originator: Service Chief of ATS/Airport Authority Head Approving Authority: Deputy Director General for Operations
103	Minimum holding altitude	Division Chief of the responsible ATS Facility/Section	Airport Authority Head	Service Chief of ATS	Deputy Director General for Operations	For establishment: Data Originator: Service Chief of ATS/Airport Authority Head Approving Authority: Deputy Director General for Operations

104	ADIZ procedure	Division Chief of the responsible ATS Facility/Section	Airport Authority Head	Service Chief of ATS	Deputy Director General for Operations	For establishment: Data Originator: Service Chief of ATS/Airport Authority Head Approving Authority: Deputy Director General for Operations
105	Air/ground facility	Department Manager of ANS Operations Department	Head of the facility directly in charge of the operation and maintenance of the communication and surveillance facility	Service Chief of CNS	Airport Authority Head	For establishment and withdrawal/decommissioning: Data Originator: Service Chief of CNS/Head of the facility directly in charge of the operation and maintenance of the communication and surveillance facility Approving Authority: Deputy Director General for Operations/Airport Authority Head
106	Automatic dependent surveillance - broadcast	Department Manager of ANS Operations Department	Head of the facility directly in charge of the operation and maintenance of the communication and surveillance facility	Service Chief of CNS	Airport Authority Head	For establishment and withdrawal/decommissioning: Data Originator: Service Chief of CNS/Head of the facility directly in charge of the operation and maintenance of the communication and surveillance facility Approving Authority: Deputy Director General for Operations/Airport Authority Head
107	Automatic dependent surveillance - contract	Department Manager of ANS Operations Department	Head of the facility directly in charge of the operation and maintenance of the communication and surveillance facility	Service Chief of CNS	Airport Authority Head	For establishment and withdrawal/decommissioning: Data Originator: Service Chief of CNS/Head of the facility directly in charge of the operation and maintenance of the communication and surveillance facility Approving Authority: Deputy Director General for Operations/Airport Authority Head
108	Controller-pilot data link communications	Department Manager of ANS Operations Department	Head of the facility directly in charge of the operation and maintenance of the communication and surveillance facility	Service Chief of CNS	Airport Authority Head	For establishment and withdrawal/decommissioning: Data Originator: Service Chief of CNS/Head of the facility directly in charge of the operation and maintenance of the communication and surveillance facility Approving Authority: Deputy Director General for Operations/Airport Authority Head
109	En-route surveillance radar	Department Manager of ANS Operations Department	Head of the facility directly in charge of the operation and maintenance of the communication and surveillance facility	Service Chief of CNS	Airport Authority Head	For establishment and withdrawal/decommissioning: Data Originator: Service Chief of CNS/Head of the facility directly in charge of the operation and maintenance of the communication and surveillance facility Approving Authority: Deputy Director General for Operations/Airport Authority Head
110	Ground controlled approach system	Department Manager of ANS Operations Department	Head of the facility directly in charge of the operation and maintenance of the communication and surveillance facility	Service Chief of CNS	Airport Authority Head	For establishment and withdrawal/decommissioning: Data Originator: Service Chief of CNS/Head of the facility directly in charge of the operation and maintenance of the communication and surveillance facility Approving Authority: Deputy Director General for Operations/Airport Authority Head
111	Selective calling system	Department Manager of ANS Operations Department	Head of the facility directly in charge of the operation and maintenance of the communication and surveillance facility	Service Chief of CNS	Airport Authority Head	For establishment and withdrawal/decommissioning: Data Originator: Service Chief of CNS/Head of the facility directly in charge of the operation and maintenance of the communication and surveillance facility Approving Authority: Deputy Director General for Operations/Airport Authority Head

112	Surface movement radar	Department Manager of ANS Operations Department	Head of the facility directly in charge of the operation and maintenance of the communication and surveillance facility	Service Chief of CNS	Airport Authority Head	For establishment and withdrawal/decommissioning: Data Originator: Service Chief of CNS/Head of the facility directly in charge of the operation and maintenance of the communication and surveillance facility Approving Authority: Deputy Director General for Operations/Airport Authority Head
113	Precision approach radar (PAR)	Department Manager of ANS Operations Department	Head of the facility directly in charge of the operation and maintenance of the communication and surveillance facility	Service Chief of CNS	Airport Authority Head	For establishment and withdrawal/decommissioning: Data Originator: Service Chief of CNS/Head of the facility directly in charge of the operation and maintenance of the communication and surveillance facility Approving Authority: Deputy Director General for Operations/Airport Authority Head
114	Surveillance radar element of precision approach radar system	Department Manager of ANS Operations Department	Head of the facility directly in charge of the operation and maintenance of the communication and surveillance facility	Service Chief of CNS	Airport Authority Head	For establishment and withdrawal/decommissioning: Data Originator: Service Chief of CNS/Head of the facility directly in charge of the operation and maintenance of the communication and surveillance facility Approving Authority: Deputy Director General for Operations/Airport Authority Head
115	Secondary surveillance radar (SSR)	Department Manager of ANS Operations Department	Head of the facility directly in charge of the operation and maintenance of the communication and surveillance facility	Service Chief of CNS	Airport Authority Head	For establishment and withdrawal/decommissioning: Data Originator: Service Chief of CNS/Head of the facility directly in charge of the operation and maintenance of the communication and surveillance facility Approving Authority: Deputy Director General for Operations/Airport Authority Head
116	Terminal area surveillance radar	Department Manager of ANS Operations Department	Head of the facility directly in charge of the operation and maintenance of the communication and surveillance facility	Service Chief of CNS	Airport Authority Head	For establishment and withdrawal/decommissioning: Data Originator: Service Chief of CNS/Head of the facility directly in charge of the operation and maintenance of the communication and surveillance facility Approving Authority: Deputy Director General for Operations/Airport Authority Head
117	Instrument landing system (ILS)	Department Manager of ANS Operations Department	Head of the facility directly in charge of the operation and maintenance of the instrument and microwave landing system	Service Chief of CNS	Airport Authority Head	For establishment and withdrawal/decommissioning: Data Originator: Service Chief of CNS/Head of the facility directly in charge of the operation and maintenance of the instrument and microwave landing system Approving Authority: Deputy Director General for Operations/Airport Authority Head
118	DME associated with ILS	Department Manager of ANS Operations Department	Head of the facility directly in charge of the operation and maintenance of the instrument and microwave landing system	Service Chief of CNS	Airport Authority Head	For establishment and withdrawal/decommissioning: Data Originator: Service Chief of CNS/Head of the facility directly in charge of the operation and maintenance of the instrument and microwave landing system Approving Authority: Deputy Director General for Operations/Airport Authority Head
119	Glide path (ILS)	Department Manager of ANS Operations Department	Head of the facility directly in charge of the operation and maintenance of the instrument and microwave landing system	Service Chief of CNS	Airport Authority Head	For establishment and withdrawal/decommissioning: Data Originator: Service Chief of CNS/Head of the facility directly in charge of the operation and maintenance of the instrument and microwave landing system Approving Authority: Deputy Director General for Operations/Airport Authority Head

120	Inner marker (ILS)	Department Manager of ANS Operations Department	Head of the facility directly in charge of the operation and maintenance of the instrument and microwave landing system	Service Chief of CNS	Airport Authority Head	For establishment and withdrawal/decommissioning: Data Originator: Service Chief of CNS/Head of the facility directly in charge of the operation and maintenance of the instrument and microwave landing system Approving Authority: Deputy Director General for Operations/Airport Authority Head
121	Localizer (ILS)	Department Manager of ANS Operations Department	Head of the facility directly in charge of the operation and maintenance of the instrument and microwave landing system	Service Chief of CNS	Airport Authority Head	For establishment and withdrawal/decommissioning: Data Originator: Service Chief of CNS/Head of the facility directly in charge of the operation and maintenance of the instrument and microwave landing system Approving Authority: Deputy Director General for Operations/Airport Authority Head
122	Middle marker (ILS)	Department Manager of ANS Operations Department	Head of the facility directly in charge of the operation and maintenance of the instrument and microwave landing system	Service Chief of CNS	Airport Authority Head	For establishment and withdrawal/decommissioning: Data Originator: Service Chief of CNS/Head of the facility directly in charge of the operation and maintenance of the instrument and microwave landing system Approving Authority: Deputy Director General for Operations/Airport Authority Head
123	Localizer (not associated with ILS)	Department Manager of ANS Operations Department	Head of the facility directly in charge of the operation and maintenance of the instrument and microwave landing system	Service Chief of CNS	Airport Authority Head	For establishment and withdrawal/decommissioning: Data Originator: Service Chief of CNS/Head of the facility directly in charge of the operation and maintenance of the instrument and microwave landing system Approving Authority: Deputy Director General for Operations/Airport Authority Head
124	Outer marker (ILS)	Department Manager of ANS Operations Department	Head of the facility directly in charge of the operation and maintenance of the instrument and microwave landing system	Service Chief of CNS	Airport Authority Head	For establishment and withdrawal/decommissioning: Data Originator: Service Chief of CNS/Head of the facility directly in charge of the operation and maintenance of the instrument and microwave landing system Approving Authority: Deputy Director General for Operations/Airport Authority Head
125	ILS Category I	Department Manager of ANS Operations Department	Head of the facility directly in charge of the operation and maintenance of the instrument and microwave landing system	Service Chief of CNS	Airport Authority Head	For establishment and withdrawal/decommissioning: Data Originator: Service Chief of CNS/Head of the facility directly in charge of the operation and maintenance of the instrument and microwave landing system Approving Authority: Deputy Director General for Operations/Airport Authority Head
126	ILS Category II	Department Manager of ANS Operations Department	Head of the facility directly in charge of the operation and maintenance of the instrument and microwave landing system	Service Chief of CNS	Airport Authority Head	For establishment and withdrawal/decommissioning: Data Originator: Service Chief of CNS/Head of the facility directly in charge of the operation and maintenance of the instrument and microwave landing system Approving Authority: Deputy Director General for Operations/Airport Authority Head
127	ILS Category III	Department Manager of ANS Operations Department	Head of the facility directly in charge of the operation and maintenance of the instrument and microwave landing system	Service Chief of CNS	Airport Authority Head	For establishment and withdrawal/decommissioning: Data Originator: Service Chief of CNS/Head of the facility directly in charge of the operation and maintenance of the instrument and microwave landing system Approving Authority: Deputy Director General for Operations/Airport Authority Head

128	Microwave landing system	Department Manager of ANS Operations Department	Head of the facility directly in charge of the operation and maintenance of the instrument and microwave landing system	Service Chief of CNS	Airport Authority Head	For establishment and withdrawal/decommissioning: Data Originator: Service Chief of CNS/Head of the facility directly in charge of the operation and maintenance of the instrument and microwave landing system Approving Authority: Deputy Director General for Operations/Airport Authority Head
129	Locator, outer (ILS)	Department Manager of ANS Operations Department	Head of the facility directly in charge of the operation and maintenance of the instrument and microwave landing system	Service Chief of CNS	Airport Authority Head	For establishment and withdrawal/decommissioning: Data Originator: Service Chief of CNS/Head of the facility directly in charge of the operation and maintenance of the instrument and microwave landing system Approving Authority: Deputy Director General for Operations/Airport Authority Head
130	Locator, middle (ILS)	Department Manager of ANS Operations Department	Head of the facility directly in charge of the operation and maintenance of the instrument and microwave landing system	Service Chief of CNS	Airport Authority Head	For establishment and withdrawal/decommissioning: Data Originator: Service Chief of CNS/Head of the facility directly in charge of the operation and maintenance of the instrument and microwave landing system Approving Authority: Deputy Director General for Operations/Airport Authority Head
131	GNSS airfield-specific operations	Department Manager of ANS Operations Department	Head of the facility directly in charge of the operation and maintenance of the GNSS services	Service Chief of CNS	Airport Authority Head	For establishment and withdrawal/decommissioning: Data Originator: Service Chief of CNS/Head of the facility directly in charge of the operation and maintenance of the GNSS services Approving Authority: Deputy Director General for Operations/Airport Authority Head
132	GNSS area-wide operations	Department Manager of ANS Operations Department	Head of the facility directly in charge of the operation and maintenance of the GNSS services	Service Chief of CNS	Airport Authority Head	For establishment and withdrawal/decommissioning: Data Originator: Service Chief of CNS/Head of the facility directly in charge of the operation and maintenance of the GNSS services Approving Authority: Deputy Director General for Operations/Airport Authority Head
133	All radio navigation facilities*	Department Manager of ANS Operations Department	Head of the facility directly in charge of the operation and maintenance of the terminal and en-route navigation facility	Service Chief of CNS	Airport Authority Head	*Used for unserviceability and change in hours of service only -For withdrawal/decommissioning: Data Originator: Service Chief of CNS/Head of the facility directly in charge of the operation and maintenance of the terminal and en-route navigation facility Approving Authority: Deputy Director General for Operations/Airport Authority Head
134	Non-directional radio beacon	Department Manager of ANS Operations Department	Head of the facility directly in charge of the operation and maintenance of the terminal and en-route navigation facility	Service Chief of CNS	Airport Authority Head	For establishment and withdrawal/decommissioning: Data Originator: Service Chief of CNS/Head of the facility directly in charge of the operation and maintenance of the terminal and en-route navigation facility Approving Authority: Deputy Director General for Operations/Airport Authority Head

135	Distance measuring equipment	Department Manager of ANS Operations Department	Head of the facility directly in charge of the operation and maintenance of the terminal and en-route navigation facility	Service Chief of CNS	Airport Authority Head	For establishment and withdrawal/decommissioning: Data Originator: Service Chief of CNS/Head of the facility directly in charge of the operation and maintenance of the terminal and en-route navigation facility Approving Authority: Deputy Director General for Operations/Airport Authority Head
136	Fan marker	Department Manager of ANS Operations Department	Head of the facility directly in charge of the operation and maintenance of the terminal and en-route navigation facility	Service Chief of CNS	Airport Authority Head	For establishment and withdrawal/decommissioning: Data Originator: Service Chief of CNS/Head of the facility directly in charge of the operation and maintenance of the terminal and en-route navigation facility Approving Authority: Deputy Director General for Operations/Airport Authority Head
137	Locator	Department Manager of ANS Operations Department	Head of the facility directly in charge of the operation and maintenance of the terminal and en-route navigation facility	Service Chief of CNS	Airport Authority Head	For establishment and withdrawal/decommissioning: Data Originator: Service Chief of CNS/Head of the facility directly in charge of the operation and maintenance of the terminal and en-route navigation facility Approving Authority: Deputy Director General for Operations/Airport Authority Head
138	VOR/DME	Department Manager of ANS Operations Department	Head of the facility directly in charge of the operation and maintenance of the terminal and en-route navigation facility	Service Chief of CNS	Airport Authority Head	For establishment and withdrawal/decommissioning: Data Originator: Service Chief of CNS/Head of the facility directly in charge of the operation and maintenance of the terminal and en-route navigation facility Approving Authority: Deputy Director General for Operations/Airport Authority Head
139	TACAN	Department Manager of ANS Operations Department	Head of the facility directly in charge of the operation and maintenance of the terminal and en-route navigation facility	Service Chief of CNS	Airport Authority Head	For establishment and withdrawal/decommissioning: Data Originator: Service Chief of CNS/Head of the facility directly in charge of the operation and maintenance of the terminal and en-route navigation facility Approving Authority: Deputy Director General for Operations/Airport Authority Head
140	VORTAC	Department Manager of ANS Operations Department	Head of the facility directly in charge of the operation and maintenance of the terminal and en-route navigation facility	Service Chief of CNS	Airport Authority Head	For establishment and withdrawal/decommissioning: Data Originator: Service Chief of CNS/Head of the facility directly in charge of the operation and maintenance of the terminal and en-route navigation facility Approving Authority: Deputy Director General for Operations/Airport Authority Head
141	VOR	Department Manager of ANS Operations Department	Head of the facility directly in charge of the operation and maintenance of the terminal and en-route navigation facility	Service Chief of CNS	Airport Authority Head	For establishment and withdrawal/decommissioning: Data Originator: Service Chief of CNS/Head of the facility directly in charge of the operation and maintenance of the terminal and en-route navigation facility Approving Authority: Deputy Director General for Operations/Airport Authority Head
142	Direction-finding station	Department Manager of ANS Operations Department	Head of the facility directly in charge of the operation and maintenance of the terminal and en-route navigation facility	Service Chief of CNS	Airport Authority Head	For establishment and withdrawal/decommissioning: Data Originator: Service Chief of CNS/Head of the facility directly in charge of the operation and maintenance of the terminal and en-route navigation facility Approving Authority: Deputy Director General for Operations/Airport Authority Head

143	Airspace reservation	Division Chief of the responsible ATS Facility/Section		Service Chief of ATS		
144	Danger area	Division Chief of the responsible ATS Facility/Section		Service Chief of ATS		For establishment and withdrawal/decommissioning: Data Originator: Service Chief of ATS Approving Authority: Deputy Director General for Operations
145	Military operating area	Division Chief of the responsible ATS Facility/Section		Service Chief of ATS		For establishment and withdrawal/decommissioning: Data Originator: Service Chief of ATS Approving Authority: Deputy Director General for Operations
146	Overflying of	Division Chief of the responsible ATS Facility/Section		Service Chief of ATS		
147	Prohibited area	Division Chief of the responsible ATS Facility/Section		Service Chief of ATS		For establishment and withdrawal/decommissioning: Data Originator: Service Chief of ATS Approving Authority: Deputy Director General for Operations
148	Restricted area	Division Chief of the responsible ATS Facility/Section		Service Chief of ATS		For establishment and withdrawal/decommissioning: Data Originator: Service Chief of ATS Approving Authority: Deputy Director General for Operations
149	Temporary restricted area	Division Chief of the responsible ATS Facility/Section		Service Chief of ATS		
150	Air display	Division Chief of the responsible ATS Facility/Section		Service Chief of ATS		
151	Aerobatics	Division Chief of the responsible ATS Facility/Section		Service Chief of ATS		
152	Captive balloon or kite	Division Chief of the responsible ATS Facility/Section		Service Chief of ATS		
153	Demolition of explosives	Division Chief of the responsible ATS Facility/Section		Service Chief of ATS		
154	Exercises (specify)	Division Chief of the responsible ATS Facility/Section		Service Chief of ATS		
155	Air refuelling	Division Chief of the responsible ATS Facility/Section		Service Chief of ATS		
156	Glider flying	Division Chief of the responsible ATS Facility/Section		Service Chief of ATS		
157	Blasting	Division Chief of the responsible ATS Facility/Section		Service Chief of ATS		
158	Banner/target towing	Division Chief of the responsible ATS Facility/Section		Service Chief of ATS		
159	Ascent of free balloon	Division Chief of the responsible ATS Facility/Section		Service Chief of ATS		
160	Missile, gun or rocket firing	Division Chief of the responsible ATS Facility/Section		Service Chief of ATS		
161	Parachute jumping exercise, paragliding or hang gliding	Division Chief of the responsible ATS Facility/Section		Service Chief of ATS		
162	Radioactive materials or toxic chemicals	Division Chief of the responsible ATS Facility/Section		Service Chief of ATS		

163	Burning or blowing gas	Division Chief of the responsible ATS Facility/Section		Service Chief of ATS		
164	Mass movement of aircraft	Division Chief of the responsible ATS Facility/Section		Service Chief of ATS		
165	Unmanned aircraft	Division Chief of the responsible ATS Facility/Section		Service Chief of ATS		
166	Formation flight	Division Chief of the responsible ATS Facility/Section		Service Chief of ATS		
167	Significant volcanic activity	Division Chief of the responsible ATS Facility/Section		Service Chief of ATS		
168	Aerial survey	Division Chief of the responsible ATS Facility/Section		Service Chief of ATS		
169	Aeronautical information service	Department Manager of AISD		Deputy Director General for Operations		
170	Obstacle	Head of airport facility directly in charge of the aerodrome/en-route obstacles or ADMS*	Head of the facility directly in charge of the aerodrome/en-route obstacles	Airport Manager or equivalent or Service Chief of ADMS*	Airport Manager or equivalent	*ADMS as Data Originator and Approving Authority on ADMS/DOTr projects, and Airport Manager on airport implemented projects.
171	Aircraft entry requirements	Service Chief of FSIS	Service Chief of FSIS	Deputy Director General for Operations	Deputy Director General for Operations	
172	Obstacle lights on...	Head of airport facility directly in charge of the aerodrome/en-route obstacles or ADMS*	Head of the facility directly in charge of the aerodrome/en-route obstacles	Airport Manager or equivalent or Service Chief of ADMS*	Airport Manager or equivalent	*ADMS as Data Originator and Approving Authority on ADMS/DOTr projects, and Airport Manager on airport implemented projects.
173	Rescue coordination centre	Division/Department Chief of the responsible ATS Facility/Section		Service Chief of ATS		For establishment and withdrawal/decommissioning: Data Originator: Service Chief of ATS Approving Authority: Deputy Director General for Operations

ANNEX B.2 AIRAC AIP AMENDMENT/AIRAC AIP SUPPLEMENT (PLANNED ACTIVITY)

	Subject/Activity	Mode of Publication (whichever is appropriate)	Condition	AIPAF Approving Authority
I	The establishment, withdrawal or significant changes to:			
1	Limits (horizontal and vertical), regulations and procedures applicable to: a. flight information regions; b. control areas; c. control zones; d. advisory areas; e. air traffic services (ATS) routes; f. permanent danger, prohibited and restricted areas (including type and periods of activity when known) and air defense identification zones (ADIZ); g. permanent areas or routes or portions thereof where the possibility of interception exists	- AIRAC AIP Amendment - AIRAC AIP Supplement	- Establishment - Withdrawal - Change	- Director General (International use) - Deputy Director General for Operations (Local use)
2	Positions, frequencies, call signs, identifiers, known irregularities and maintenance periods of radio navigation aids, and communication and surveillance facilities	- AIRAC AIP Amendment - AIRAC AIP Supplement	- Establishment - Withdrawal - Change	- Deputy Director General for Operations/Airport Authority Head (Establishment/Withdrawal) - Service Chief of CNS/Airport Authority Head (Change)
3	Holding and approach procedures, arrival and departure procedures, noise abatement procedures and any other pertinent ATS procedures	- AIRAC AIP Amendment - AIRAC AIP Supplement	- Establishment - Withdrawal - Change	- Deputy Director General for Operations (Establishment/Withdrawal) - Service Chief of ATS (Change)
4	Transition levels, transition altitudes and minimum sector altitudes	- AIRAC AIP Amendment - AIRAC AIP Supplement	- Establishment - Withdrawal - Change	- Service Chief of ATS
5	Meteorological facilities (including broadcasts) and procedures	- AIRAC AIP Amendment - AIRAC AIP Supplement	- Establishment - Withdrawal - Change	- Deputy Director General for Operations/Airport Authority Head (Establishment/Withdrawal) - Service Chief of CNS (Change)
6	Runways and stopways	- AIRAC AIP Amendment - AIRAC AIP Supplement	- Establishment - Withdrawal - Change	- Deputy Director General for Operations/Airport Authority Head (Establishment/Withdrawal) - Airport Manager or equivalent (Change)

7	Taxiways and aprons	- AIRAC AIP Amendment - AIRAC AIP Supplement	- Establishment - Withdrawal - Change	- Deputy Director General for Operations/Airport Authority Head (Establishment/Withdrawal) - Airport Manager or equivalent (Change)
8	Aerodrome ground operating procedures (including low visibility procedures)	- AIRAC AIP Amendment - AIRAC AIP Supplement	- Establishment - Withdrawal - Change	- Service Chief of ATS
9	Approach and runway lighting	- AIRAC AIP Amendment - AIRAC AIP Supplement	- Establishment - Withdrawal - Change	- Deputy Director General for Operations/Airport Authority Head (Establishment/Withdrawal) - Service Chief of CNS (Change)
10	Aerodrome operating minima if published	- AIRAC AIP Amendment - AIRAC AIP Supplement	- Establishment - Withdrawal - Change	- Deputy Director General for Operations (Establishment/Withdrawal/Change) - Service Chief of ATS (Change in procedures)
II The establishment and withdrawal of, and premeditated significant changes in:				
1	Position, height and lighting of navigational obstacles	- AIRAC AIP Amendment - AIRAC AIP Supplement	- Establishment - Withdrawal - Change	- Airport Manager or equivalent - Service Chief of ATS (Obstacles infringing flight procedures/ Visual Segment Surface)
2	Hours of service of aerodromes, facilities and services	- AIRAC AIP Amendment - AIRAC AIP Supplement	- Establishment - Withdrawal - Change	- Deputy Director General for Operations/Airport Authority Head (Aerodrome) - Service Chief of ATS/CNS (Facilities and Services)
3	Customs, immigration and health services	- AIRAC AIP Amendment - AIRAC AIP Supplement	- Establishment - Withdrawal - Change	Director General
4	Temporary danger, prohibited and restricted areas and navigational hazards, military exercises and mass movements of aircraft	- AIRAC AIP Supplement	- Establishment - Withdrawal - Change	- Deputy Director General for Operations (Establishment/Withdrawal) - Service Chief of ATS (Change)
5	Temporary areas or routes or portions thereof where the possibility of interception exists	- AIRAC AIP Supplement	- Establishment - Withdrawal - Change	- Deputy Director General for Operations (Establishment/Withdrawal) - Service Chief of ATS (Change)

III The establishment of, and premeditated major changes in:				
1	New aerodromes for international instrument flight rules (IFR) operations;	- AIRAC AIP Amendment - AIRAC AIP Supplement	Establishment	- Director General
2	New runways for IFR operations at international aerodromes	- AIRAC AIP Amendment - AIRAC AIP Supplement	Establishment	- Director General
3	Design and structure of the ATS route network	- AIRAC AIP Amendment - AIRAC AIP Supplement	- Establishment - Change	- Director General - Service Chief of ATS (Change only)
4	Design and structure of a set of terminal procedures (including change of procedure bearings due to magnetic variation change)	- AIRAC AIP Amendment - AIRAC AIP Supplement	- Establishment - Change	- Director General - Service Chief of ATS (Change only)
5	Circumstances listed in item I, if the entire State or any significant portion thereof is affected or if cross-border coordination is required.	- AIRAC AIP Amendment - AIRAC AIP Supplement	Establishment	- Director General

Note: See section III item 9 of this AIC for the concurrence and coordination with the Appropriate Authority.